



Operating & Safety Guidelines

Soup Kettle - KEEP out of reach of children.

Suitable for indoor use only

WARNING: only move the urn when it is disconnected and cool.

Never use the equipment if you are ill, tired or under the influence of alcohol or drugs.

Never operate electrical switches with wet hands.

Never operate electrical switches with wet hands.

Always switch off and unplug the equipment from the power supply before moving or cleaning.

ELECTRICAL SAFETY

- The equipment is designed to plug directly into a standard 240volt, 13 amp socket.
- Make sure the equipment and power socket are switched off before plugging into the power supply.
- Keep the power cable out of harm's way.
- Extension leads should be unwound fully, never run them through water, over sharp objects or where they may be a trip hazard.
- Use a suitable RCD (Residual Current Operated Device) to reduce the risk of electric shock.
- Ensure the water boiler and power socket are switched off before plugging in.

OPERATING GUIDE

- Position the unit where it is to be used and ensure that it is level. Ensure the surface is strong enough to take the weight when full; the unit is heavy when full.
- The unit should be positioned to give easy access to the user yet sufficiently out of the way to reduce the risk of it being touched or knocked.
- Do not place the appliance where the mains lead could fall into a sink.
- Keep power cable out of harms way.
- Connect the appliance to the mains power supply.

FILL THE OUTER CONTAINER WITH APPROXIMATELY 600ml OF WATER

Note: Never operate the appliance without water in the outer container.

-Carefully place the inner container into the appliance.

Note: The inner container must NOT float, even when empty. If the container floats, reduce the amount of water in the outer container.

- Fill the inner container with soup and close the lid.

Note: If necessary, remove any excess water from the outer container.

-Set the temperature control, the temperature ranges from 1 (lowest) to 12 (highest). The power light will come on and the kettle will begin to heat up.

-Stir regularly to achieve quicker heat up times.

At full power, a full kettle can take up to 90 minutes to heat through from cold.

When the kettle has reached temperature the Power light will switch off. Reduce the temperature to maintain heat levels. To maintain temperature, we recommend the lowest setting possible. Use a suitable implement to remove the contents of the kettle.

DO NOT TIP THE KETTLE TO REMOVE THE CONTENTS.

To turn the appliance Off, set the temperature control to '0'

EQUIPMENT CARE

- Always ensure there is sufficient water to cover the heating element, but never overfill or it could boil over.
- Do not let the unit boil dry, the heater element may burn out.
- Once you have finished with the unit, switch off and unplug. Allow the unit to cool completely before draining off as much water as possible via the dispensing tap.

Any problems please call 01789 491133

