



Operating & Safety Guidelines Parry Hot Holding Cupboard

Never operate electrical switches with wet hands.

Always switch off and unplug the equipment from the power supply before moving or cleaning.

ELECTRICAL SAFETY

- The equipment is designed to plug directly into a standard 240volt, 13 amp socket.
- Make sure the equipment and power socket are switched off before plugging into the power supply.
- Keep the power cable out of harm's way.
- Extension leads should be unwound fully, never run them through water, over sharp objects or where they may be a trip hazard.
- Use a suitable RCD (Residual Current Operated Device) to reduce the risk of electric shock.

OPERATING GUIDE

DO NOT USE THIS MACHINE FOR COOKING PURPOSES

- Turn on the power supply, the red lamp will illuminate to indicate the power is on.
- Turn the thermostat dial to the required setting, the green lamp will show indicating that there is power to the element
- When the desired temperature is reached the green lamp will extinguish, this procedure will be repeated automatically as the thermostat maintains a constant temperature.
- Place the gastronorm containers on racks
- After use ensure machine is switched off, plug pulled out and unit is isolated from the power supply

WATER TRAY

- A small water tray is fitted to the base of the unit to allow water to be added to give moisture if required. If using do NOT over fill

CLEANING

- Please ensure machine is switched off after use and disconnected and isolated from a power supply
- Wipe interior and exterior clean with a damp cloth when cool.
- Do not use sharp objects, metal scrapers, wire brushes or wire wool pads as they can scratch the steel
- Do not use bleach or any corrosive detergent as they will damage the surface of the unit.

FAULT FINDING

The most common fault is that the unit is not connected to the mains supply, and so the mains lamp will not illuminate, in this circumstance please try the following before calling for service assistance.

- Check the unit is plugged into the mains supply and the socket is switched on.
- Check the fuse in the plug
- Try a different socket

Any problems please call 01789 491133